

Pressure Sensitive Vinyl Installation Instructions

Surface Preparation

All surfaces must be considered dirty and must be cleaned prior to the application of decals. Recommended cleaning procedures for specific surfaces are listed below

Saturate a clean cloth with a 2-to-1 mixture of water and Isopropyl alcohol and wipe surface. (Cleaners such as Windex Window Cleaner may be used.) Wipe surface dry with a clear dry, lint-free cloth.

Temperature Requirements

Air and application surface temperatures must be above 55 degrees

Application Instructions

1. Use 1" – 2" (2.5 – 5cm) strips of masking tape to position the decal in proper registry.
2. Apply horizontal tape hinge at the top of the decal to allow decal to be lifted up from the bottom.
3. A small bend at a corner or edge will allow the liner to separate from the decal. Pull the liner away from the decal in a continuous motion at a 180 degree angle. Lift decal and remove liner entirely.
4. Be sure decal is flat and tight. Using firm initial squeegee pressure, begin at top center and work down and outward to each edge of decal.
5. Overlap sections by .25"w. Pattern will line up with images.
6. Re-squeegee entire decal.
7. Apply light heat from a hairdryer or heat gun. **WARNING!** Do not get closer than 8" to vinyl, it will burn if too close to material